

# American Darling Hydrant

## Hydrant Upper Rod Replacement Procedure

### B50B Monitor Spool Models

1. Be sure to use all appropriate safety equipment during this procedure.
2. Close the control valve to isolate the hydrant from line pressure.
3. Remove one nozzle cap and open the hydrant several turns to relieve the pressure in the hydrant and to make certain the water is shut off. Collect a bucket of water at this time to help with the cleaning process.
4. Return the hydrant to the closed position.
5. Remove the two (2) housing bolts & nuts #16 holding the hydrant cover #7 in place and set aside for re-use.
6. Remove the hydrant cover #7.
7. Remove the four (4) housing cover cap screws #11-2.
8. Remove the housing cover #9 and cover gasket #13 and set aside for re-use.
9. Remove the ball bearing #4 and discard.
10. Unscrew the operating nut #1.
11. Turn the operating nut upside down and fill the internal cavity approximately  $\frac{1}{4}$  to  $\frac{1}{2}$  full of environmentally friendly solvent cleaner such as Simple Green® or other appropriate commercial solvent base de-greaser.
12. Covering the operating nut opening, shake several times to loosen and dissolve grease and any loose debris.
13. Using the bottle brush provided, with a twisting motion, insert the brush into the threaded hole in the operating nut.
14. Remove the bottle brush and drain the solvent from the operating nut. Clean the bottle brush periodically with water to remove solvent and grease. Repeat this cleaning procedure a second time to remove all existing grease. Rinse internal cavity with water to remove all traces of solvent. Set the operating nut aside for re-use.  
**NOTE: Properly dispose of the solvent in accordance with local and/or state requirements.**
15. Remove the remaining housing bolts & nuts #16 and set aside for re-use. Carefully lift and remove the housing #15. If the housing gasket #14 was removed with the housing, clean it for re-use. If it was left on the monitor elbow, remove and set aside for re-use.
16. Using a wooden paddle supplied, remove all existing grease from the internal cavity of the housing #15.

17. Spray some environmentally friendly solvent cleaner or other appropriate commercial solvent base de-greaser into the recess of the housing. Using the bottle brush provided, scrub the internal cavity of the housing to remove all existing grease. Clean the bottle brush periodically with water to remove solvent and grease. Repeat this cleaning procedure a second time to remove all existing grease. Rinse the internal cavity with water to remove all traces of solvent.
18. Using a hydrant seat wrench, slide the square socket portion of the wrench over the upper hydrant rod engaging the square portion of the upper rod.
19. Turn the seat wrench counter-clockwise approximately ten (10) turns.
20. Remove the seat wrench.
21. While using hand protection, lift the rod and attached internal parts from the hydrant.
22. Remove the upper rod cotter pin and coupling pin #29-31 located at the ground line connection. If the hydrant was retrofitted with a monitor elbow after leaving the factory, the upper rod #30-11 and short rod extension will be replaced with a single long upper rod.
23. Remove the upper rod #30-11 from the rod coupling #29-30 and replace with a new upper rod supplied with the kit, making sure the half hole in the upper rod lines up with the hole in the rod coupling.
24. Re-install the rod coupling pin and cotter pin removed earlier. If the pin was damaged, replace it with a new pin and cotter pin. After the pin is installed, pull on the upper rod to make sure it is locked to the rod coupling.
25. Check the hydrant seat gasket #36 to insure it is in place and undamaged.
26. Replace the hydrant seat gasket #36 if needed with new gasket from the kit.
27. Using the paint brush, grease the hydrant seat threads and seat gasket with a liberal amount of the Mystic Food Grade grease supplied in the kit.
28. Carefully lift the hydrant rod assembly and slowly lower it into the hydrant barrel until it stops, pushing down on the upper rod to insure the hydrant seat is in the proper position.
29. Put the hydrant seat wrench over the upper rod and slowly turn the hydrant rod assembly counter-clockwise up to one full turn. This will align the start of the threads and prevent cross-threading.
30. Turn the hydrant rod assembly clockwise until it tightens. Apply 70-80 foot-lbs. of torque using only the seat wrench.
31. Replace the housing O-ring #2-2 with the O-ring supplied in the kit. Lubricate the housing o-ring with the Mystic Food Grade grease.
32. Lower the housing over the upper rod, using caution to protect the housing o-ring, and align the bolt holes on the housing and upper barrel, making sure the housing gasket #14 is in place on the monitor elbow or on the housing.
33. Re-install all housing bolts and nuts #16 except the two (2) for the hydrant cover.
34. With the housing centered, tighten the bolts and nuts to 80 foot-pounds.

35. Using a grease gun, apply an approximately 2" deep layer of Mystic Food Grade grease into the bottom of the top housing cavity.
36. Using a grease gun, apply the Mystic Food Grade grease around the upper rod and into the housing cavity. Grease should be applied to fill the entire cavity of the top housing.
37. Using the paint brush, apply the Mystic Food Grade grease to the threads of the upper rod.
38. Using a grease gun, fill the internal cavity of the operating nut #1 approximately ½ full of Mystic Food Grade grease. Ensure grease is present on the threaded portion of the operating nut.
39. Thread the operating nut on the upper rod. Install the ball bearing #4 included in the kit on top of the operating nut collar and lubricate with the Mystic Food Grade grease.
40. Hand tighten the operating nut to close the hydrant. **DO NOT OVER TIGHTEN.**
41. Install the cover gasket #13. If damaged, replace with new cover gasket supplied with repair kit.
42. Clean the housing cover #9 previously removed and re-install with the four (4) housing cover cap screws #11-2.
43. Tighten the cap screws with 30 foot-pounds of torque and turn the operating nut to assure free rotation.
44. Install the weather cover #7 and REPAIR TAG with the remaining two (2) housing bolts and nuts. The REPAIR TAG should be positioned on top of the weather cover. Place a washer on top of the REPAIR TAG before inserting the housing bolt to minimize the tendency of the repair tag to rotate during tightening. [See diagram included in REPAIR TAG bag.] The REPAIR TAG will identify the hydrant as having been repaired. Tighten the bolts to 80 foot-pounds.
45. Make sure the hydrant is closed; then open the water control valve.
46. With a nozzle cap removed, slowly open the hydrant to check for proper operation and joint tightness. If the rod coupling pin, cotter pin, and/or any other items were dropped into the hydrant during the repair procedure, they must be flushed out during the operational test.
47. Close the hydrant after the operational test.
48. Ensure all nuts, bolts, and the pipe plug are securely tightened.

**Please contact American Flow Control at [800-326-7082](tel:800-326-7082) if you have any questions regarding this procedure, or if additional parts are needed.**